



## ENGLISH

### TABLE BLENDER VT-3416 BK

This unit is intended for chopping products, mixing different ingredients or making cocktails.

#### DESCRIPTION

1. Lid plug/measuring cup
2. Blender bowl lid
3. Glass bowl
4. Bowl handle
5. Blender bowl base
6. Knife block
7. Sealing gasket
8. Motor unit
9. Operation mode switch «P-0-I-II»
10. Non-slip feet

#### SAFETY MEASURES

Read this instruction manual carefully before using the unit and keep it for the whole operation period.

Use the unit according to its intended purpose only, as it is stated in this user manual. Mishandling the unit can lead to its breakage and cause harm to the user or damage to his/her property.

- Before connecting the unit to the mains, make sure that the voltage specified on the unit corresponds to your home mains voltage.
- Do not use the unit outdoors.
- Always unplug the unit when you are not using it.
- The knife block cutting edges are very sharp and dangerous. Handle the knife block very carefully when dismantling the unit or removing the processed food from the blender bowl.

**Note:** If food processing is hard, add some liquid (water, liquor, juice) into the blender bowl (3).

Before you start chopping/mixing, we recommend to peel fruit, remove inedible parts, such as stones, and to cut fruit into approximately 2x2 cm cubes.

**ATTENTION!** Continuous operation time of the blender should not exceed 2 minutes, and the break between operations should be 3-5 minutes.

#### CLEANING AND CARE

After the unit operation is finished, switch the blender off by setting the operation mode switch (9) to the "0" position and unplug it.

- Remove the blender bowl (3) from the motor unit (8) by turning it counter-clockwise.
- Take the processed products out of the bowl (3).
- Wash the bowl (3) preliminarily.
- Remove the knife block (6) and the sealing gasket (7) from the bowl base (5). To remove the knife block (6), turn it in the direction of the "OPEN" arrow and remove it (fig.1).

**WARNING:** The knife block cutting edges are very sharp and dangerous. Handle the knife block very carefully.

Wash the bowl (3), the knife block (6) and the sealing gasket (7) with warm water and soft detergent and dry them.

- Do not allow children to touch the motor unit and the power cord during the unit operation.
- Clean the unit body with a soft damp cloth and then wipe it dry.

• Do not use coarse sponges, abrasives and solvents to clean the blender.

**Do not immerse the blender motor unit (8) into any liquids; do not wash it in a dishwashing machine.**

Set the sealing gasket (7) on the knife block (6).

Install the knife block (6) into the blender bowl base (5) and turn them in the direction of the "LOCK" arrow.

#### STORAGE

Perform the requirements of the "CLEANING AND CARE" section before taking the unit away for storage.

Keep the unit away from children in a clean and dry place.

#### Food processing examples

Specified processing time is approximate and depends on the products quality, their quantity and chopping degree.

es on the cup (1) with the grooves on the lid (2) and turn the cup (1) clockwise until bumping.

- Make sure once again that the blender bowl (3) is installed correctly and fixed.
- Insert the power plug into the mains socket.

**Note:** The blender will not be switched on if the blender bowl (3) is installed incorrectly.

- Use the operation mode switch (9) to set the required speed of knives rotation:
- «1» (low speed) – for mixing liquid products.
- «2» (high speed) – for liquid and hard products.
- «P» – pulse mode.

• During the operation or between the operations you can add the required ingredients into the bowl (3). To do this, turn the lid plug/measuring cup (1) counterclockwise and remove it, you can use the cup (1) as a bowl for adding necessary liquid ingredients. After adding the ingredients, place the cup (1) back to its place and turn it clockwise until bumping.

- After the unit operation is finished, set the operation mode switch (9) to the "0" position and unplug the unit.
- Remove the blender bowl (3) from the motor unit (8) by turning it counter-clockwise.

• Before connecting the unit to the mains, make sure that the voltage specified on the unit corresponds to your home mains voltage.

• Do not use the unit outdoors.

• Always unplug the unit when you are not using it.

• The knife block cutting edges are very sharp and dangerous. Handle the knife block very carefully when dismantling the unit or removing the processed food from the blender bowl.

**Note:** If food processing is hard, add some liquid (water, liquor, juice) into the blender bowl (3).

Before you start chopping/mixing, we recommend to peel fruit, remove inedible parts, such as stones, and to cut fruit into approximately 2x2 cm cubes.

**ATTENTION!** Continuous operation time of the blender should not exceed 2 minutes, and the break between operations should be 3-5 minutes.

#### CLEANING AND CARE

After the unit operation is finished, switch the blender off by setting the operation mode switch (9) to the "0" position and unplug it.

- Remove the blender bowl (3) from the motor unit (8) by turning it counter-clockwise.
- Take the processed products out of the bowl (3).

• Remove products and pour out liquids from the blender bowl only after complete stop of the knives.

• When unplugging the unit, hold the plug; do not pull the power cord.

• Do not let the cord hang from the edge of the table and make sure it does not touch hot surfaces or sharp edges of furniture.

• Do not touch the power plug with wet hands.

• Do not leave the operating unit unattended.

• Do not use the unit near the kitchen sink; do not expose the unit to moisture.

• To avoid electric shock, do not immerse the power cord, the power plug and the motor unit in water or any other liquids.

• Do not allow children to touch the motor unit and the power cord during the unit operation.

• Do not allow children to use the blender as a toy.

• Clean the unit body with a soft damp cloth and then wipe it dry.

• Do not use coarse sponges, abrasives and solvents to clean the blender.

**Do not immerse the blender motor unit (8) into any liquids; do not wash it in a dishwashing machine.**

Set the sealing gasket (7) on the knife block (6).

Install the knife block (6) into the blender bowl base (5) and turn them in the direction of the "LOCK" arrow.

#### STORAGE

Perform the requirements of the "CLEANING AND CARE" section before taking the unit away for storage.

Keep the unit away from children in a clean and dry place.

#### Food processing examples

Specified processing time is approximate and depends on the products quality, their quantity and chopping degree.

## DEUTSCH

### STANDMIXER VT-3416 BK

Das Gerät ist für Zerkleinerung von Nahrungsmitteln, Mixen von verschiedenen Zutaten oder Zubereitung von Mixgetränken geeignet.

#### BESCHREIBUNG

1. Deckelpropfen/Messbecher
2. Deckel des Mixerbehälters
3. Standmixer
4. Befestigungsschraube
5. Boden des Mixerbehälters
6. Messerblock
7. Dichtung
8. Motoreinheit
9. Betriebsstufenschalter «P-0-I-II»
10. Rutschfeste Füße

#### SICHERHEITSMASNAHMEN

Vor der ersten Inbetriebnahme des Geräts lesen Sie die Bedienungsanleitung aufmerksam durch und bewahren Sie sie während der ganzen Betriebszeit des Geräts.

Benutzen Sie dieses Gerät nur bestimmungsmäßig und laut dieser Bedienungsanleitung. Unzulässige Nutzung des Geräts kann zu Störungen führen, die gesundheitlichen oder materiellen Schaden beim Nutzer hervorrufen.

- Vor dem Anschließen des Geräts an den Betrieb stellen Sie den Betriebsstufenschalter (9) in die Position "0" und ziehen Sie den Netzstecker aus der Steckdose heraus.
- Nehmen Sie das Messerbeholder (3) von der Motoreinheit (8) ab, indem Sie ihn entgegen dem Uhrzeigersinn drehen.
- Nehmen Sie den Deckel (2) vom Mixerbeholder (3) ab und nehmen Sie die verarbeiteten Nahrungsmittel aus dem Mixerbeholder (3) heraus.
- Bevor Sie das Getränk anschließen, prüfen Sie, ob die Spannung des Geräts mit der Netzspannung übereinstimmt.
- Es ist nicht gestattet, das Gerät draußen zu benutzen.
- Nehmen Sie den Deckel (2) vom Mixerbeholder (3) ab und nehmen Sie die verarbeiteten Nahrungsmittel aus dem Mixerbeholder (3) heraus.
- Die Schneidekanten des Messerblocks sind sehr scharf und gefährlich. Gehen Sie mit dem Messerblock sehr vorsichtig um, wenn Sie das Gerät auseinandernehmen oder die verarbeiteten Nahrungsmittel aus dem Mixerbeholder herausnehmen, sowie während der Reinigung!
- Lassen Sie keine Nahrungsmittel abkühlen, soll die Temperatur 70°C nicht übersteigen.
- Es darf nicht gestattet, ohne Nahrungsmittel zur Bearbeitung einzuschalten.
- Trennen Sie das Gerät im Falle der unverhofften Unterbrechung der Messerdrehung vom Stromnetz ab, und erst danach dürfen Sie die Messerdrehung blockierten Zutaten entfernen.
- Es ist nicht gestattet, den Mixerbeholder mit Produkten zu überlasten, beachten Sie den Füllstand der zugegebenen Flüssigkeiten.
- Nehmen Sie Nahrungsmittel heraus und gießen Sie Flüssigkeiten aus dem Mixerbeholder erst dann ab, wenn die Messer völlig gestoppt haben.

#### REINIGUNG UND PFLEGE

Schalten Sie den Standmixer nach der Beendigung des Betriebs aus, indem Sie den Betriebsstufenschalter (9) in die Position "0" stellen, und ziehen Sie den Netzstecker aus der Steckdose heraus.

• Nicht! Sie können die Messerbeholder (3) aus der Motoreinheit (8) ab, indem Sie ihn entgegen dem Uhrzeigersinn drehen.

• Nehmen Sie die verarbeiteten Nahrungsmittel aus dem Mixerbeholder (3) heraus.

• Spülen Sie den Behälter (3) vorher ab.

• Nehmen Sie den Messerblock (6) und die Dichtung (7) aus dem Boden des Mixerbehälters (5) heraus. Zum Abnehmen des Messerblocks (6) drehen Sie die Messer in der Richtung des Zeigers "OPEN" und nehmen Sie sie ab (Abb. 1).

#### ANMERKUNG:

Falls das Nahrungsmittel schwer zu bearbeiten sind, geben Sie eine kleine Menge Flüssigkeit (Wasser, Brühe, Saft) in den Mixerbeholder (3) zu.

Es ist empfohlen, Schale und alle nicht essbaren Reste, wie z.B. Fruchtkerne, vor der Zerkleinerung/Mixen zu entfernen, und Früchte in Würfel ca. 2x2 cm zu schneiden.

**ACHTUNG!** Der Dauerbetrieb des Standmixers soll 2 Minuten nicht übersteigen, und die Betriebspausen sollen von 3 bis 5 Minuten betragen.

#### REINIGUNG UND PFLEGE

Schalten Sie den Standmixer nach der Beendigung des Betriebs aus, indem Sie den Betriebsstufenschalter (9) in die Position "0" stellen, und ziehen Sie den Netzstecker aus der Steckdose heraus.

• Nicht! Sie können die Messerbeholder (3) aus der Motoreinheit (8) ab, indem Sie ihn entgegen dem Uhrzeigersinn drehen.

• Nehmen Sie die verarbeiteten Nahrungsmittel aus dem Mixerbeholder (3) heraus.

• Spülen Sie den Behälter (3) vorher ab.

• Nehmen Sie den Messerblock (6) und die Dichtung (7) aus dem Boden des Mixerbehälters (5) heraus. Zum Abnehmen des Messerblocks (6) drehen Sie die Messer in der Richtung des Zeigers "OPEN" und nehmen Sie sie ab (Abb. 1).

#### ANHOTUNG:

Die Schneidekanten des Messerblocks sind sehr scharf und gefährlich. Gehen Sie mit dem Messerblock sehr vorsichtig um.

• Waschen Sie den Mixerbeholder (3), den Messerblock (6) und die Dichtung (7) mit Warmwasser und einem neutralen Waschmittel, und danach trocken Sie sie ab.

• Es ist nicht gestattet, den Standmixer Kindern als Spielzeug zu geben.

• Dieses Gerät ist nicht für den Gebrauch von Kindern unter 8 Jahren geeignet.

• Während des Betriebs und der Betriebspausen stellen Sie das Gerät an einem sichereren Ort auf.

• Dieses Gerät darf von Kindern ab 8 Jahren und behinderten Personen nur dann genutzt werden, wenn sie sich unter Aufsicht der für ihre Sicherheit verantwortlichen Person befinden, und wenn ihnen entsprechende und verständliche Anweisungen über sichere Nutzung des Geräts und die Gefahren bei seiner falschen Nutzung geworben wurden.

• Aus Kindersicherheitsgründen lassen Sie die Plastiktüten, die als Verpackung verwendet werden, nie ohne Aufsicht.

**Achtung!** Lassen Sie Kinder mit Plastiktüten oder Verpackungsfolien nicht spielen.

• Prüfen Sie das Gerät zur Aufbewahrung wegpacken, bevor Sie die Anforderungen des Abschnitts „REINIGUNG UND PFLEGE“.

• Bewahren Sie das Gerät an einem sauberen, trockenen und für Kinder unzugänglichen Ort auf.

#### BEFESTIGUNG

• Bevor Sie das Gerät zur Aufbewahrung wegpacken, entfernen Sie die Anforderungen des Abschnitts „REINIGUNG UND PFLEGE“.

• Bewahren Sie das Gerät an einem sauberen, trockenen und für Kinder unzugänglichen Ort auf.

#### AUFBEWAHRUNG

• Bevor Sie das Gerät zur Aufbewahrung wegpacken, entfernen Sie die Anforderungen des Abschnitts „REINIGUNG UND PFLEGE“.

• Bewahren Sie das Gerät an einem sauberen, trockenen und für Kinder unzugänglichen Ort auf.

#### REINIGUNG UND PFLEGE

Die angegebene Bearbeitungsdauer ist annähernd und hängt von der Qualität, Menge und Zerkleinerungsgrad der Nahrungsmittel ab.

#### DAS GERÄT IST NUR FÜR DEN GEBRAUCH IM HAUSHALT GEIGNET

#### Vorbereitung zur Inbetriebnahme

**Falls das Gerät unter niedrigen Temperaturen transportiert oder gelagert wurde, lassen Sie es vor der Nutzung bei der Raumtemperatur mindestens weniger als zwei Stunden stehen.**

Pecken Sie das Gerät völlig aus und entfernen Sie alle Aufkleber, die den Gerätetrieb stören.

• Prüfen Sie die Ganzheit des Geräts; wenn das Gerät beschädigt ist, benutzen Sie es nicht.

