


# Multi-language quick guide

## Instructions for Connecting the Speakers



## Control Functions



**EN**

### **Connect the speaker system to the PC**

1. Connect the speaker system to the PC by using the PC speaker's "SPEAKER OUT" jack.
2. Connect the speaker system to the PC by using the speaker system's "SPEAKER IN" jack.
3. Connect the PC to any word processor, data entry program, a form software, such as PC, ... software, MP3/MP4 player, photo printer, or full page.

### **Control**

1. Press "L" to control the speaker.
2. Press "R" to control the speaker.
3. Press "ON/OFF" to control the speaker.

### **Power**

1. Press "ON/OFF" to power on/off the speaker.
2. Press "ON/OFF" to power on/off the speaker for a long time.

**FR**

### **Connecter le systeme de haut-parleur au PC**

1. Connecter le systeme de haut-parleur au PC en utilisant la prise "SPEAKER OUT" du PC.
2. Connecter le systeme de haut-parleur au PC en utilisant la prise "SPEAKER IN" du systeme de haut-parleur.
3. Connecter le PC a tout logiciel de traitement de texte, de saisie de donnees, de logiciels de formes, tels que PC, ... logiciel, lecteur MP3/MP4, imprimante photo, ou logiciel de page complete.

### **Control**

1. Appuyer sur "L" pour commander le haut-parleur.
2. Appuyer sur "R" pour commander le haut-parleur.
3. Appuyer sur "ON/OFF" pour commander le haut-parleur.

### **Power**

1. Appuyer sur "ON/OFF" pour allumer/eteindre le haut-parleur.
2. Appuyer sur "ON/OFF" pour allumer/eteindre le haut-parleur pendant une longue periode.