HOW TO ATTACH YOUR CAMERA TO THE WALKING STICKS.



2B

HOW TO REGULATE THE HEIGHT.



4


STOP
5
90°
6
HOW TO USE THE ACCESSORIES.
7


HOW TO REGULATE THE HEIGHT.
1
2
3
4