



F	Service consommateurs & commande accessoires	09 74 50 47 74
B	Service consommateurs Consumentendienst	070/23 21 59
NL	Consumenten-service	+ 31 318 58 24 24
D	Kundenservice	+ 49 212 387 400
I	Servizio consumatori	+ 39 199 20 73 54
GB	Consumer Service & Accessories ordering	44 845 725 85 88
E	Servicio al consumidor	+ 34 902 312 400
P	Clube Consumidor	+ 351 808 284 735
GR		+ 30 801 11 97 101 + 30 210 63 71 251
TR	Müşteri hizmetleri	444 40 50
DK	Kundeservice	+ 45 4466 31 55
S	Kundeservice	+ 46 8 594 213 30
FIN	Asiakaspalvelu	+ 358 962 29 420
N	Kundeservice & bestilling av reservedeler	+ 47 815 09 567
RUS		+ 40 213 10 34 47
UA		+ 38 044 417 64 13
PL		+ 48 801 300 421
CZ		+ 420 222 31712 7
SK		+ 421 4488 71 24
H		+ 36 1801 84 34
SR		
SLO		+ 386 22 50 9230
BG		+ 070 010 218
RO		+ 40 (21) 233.13.45
HR		+ 385 1 3015 294

BATHROOM SCALES WITH MEMO


Pèse-personne à mémoires



1




A




B




C



D




E




F


2




A




B



C



D



E

