




2big dual

eSATA & Hi-Speed USB 2.0



Quick Install Guide

Box Content

LaCie 2big Dual with two swappable disks

eSATA to eSATA cable

Hi-Speed USB 2.0 cable

External power supply

Removable stand (for upright position)


LaCie Storage Utilities CD-ROM (with detailed user manual)

CD-ROM including EMC® Retrospect® Express backup software &

LaCie Shortcut Button software




Protect your investment – register for free technical support: www.lacie.com/register



Front View

1. Front LED and LaCie
Shortcut Button
2. Removable stand
(for upright position)




Rear View

- | | |
|-----------------------------|-------------------------------|
| 3. RAID selection switch | 8. USB 2.0 port |
| 4. Left drive status LED | 9. Confirm button |
| 5. Right drive status LED | 10. Disk lock |
| 6. off/auto/on power switch | 11. Disk tray handle |
| 7. eSATA port | 12. Power input
connection |

Setup

1. Plug the power supply into an AC outlet and connect the power cable to the 2big.
2. Decide which interface cable you will use:
 - a. **eSATA Connection:** Connect the eSATA cable to your computer and to the 2big.
 - b. **USB 2.0 Connection:** Connect the USB 2.0 cable to your computer and to the 2big.

NOTE: If both a USB and an eSATA cable are connected, the USB connection will remain active and the eSATA connection will be disabled.



3. Turn on the 2big by moving the power switch on the back to the **ON** position.
4. The LaCie 2big Dual comes with two 3.5" SATA II hard disks installed. The disks are formatted in NTFS, so Mac users will need to reformat the disks before using the 2big. Please see the User Manual on the LaCie Storage Utilities CD for information on formatting hard disks.

The 2big is configured in FAST mode (RAID 0). If you would like to change the RAID mode, see Changing the RAID Mode on the next page.

5. **Install LaCie Shortcut Button software to enable the feature.**

Changing the RAID Mode (Optional)



CAUTION! Changing configuration modes destroys data stored on the 2big.

Back up data before following these steps.

CAUTION! Disks must be inserted correctly in the 2big before configuration can be changed.

NOTE: See the User Manual for information on RAID modes.

1. Unmount or safely remove the 2big volumes from your computer.
Do not turn off the 2big.
2. Insert a small, flat-blade screwdriver into the groove on the rotary switch and turn the screwdriver to the left or right to select a different mode.
3. Remove the screwdriver from the rotary switch and use it to depress the confirm button.
The two drive status LEDs blink quickly to confirm the RAID mode change.
4. Reformat the disks. Please refer to the user manual on the LaCie Storage Utilities CD-ROM.



RU Установка

1. Подключите источник питания к розетке, а кабель питания — к системе 2big.
 2. Выберите кабель интерфейса.
 - А. Подключение с помощью кабеля eSATA:** подключите кабель интерфейса eSATA к компьютеру и системе 2big.
 - Б. Подключение с помощью кабеля USB 2.0:** подключите кабель интерфейса USB 2.0 к компьютеру и системе 2big.
- ПРИМЕЧАНИЕ. Если подключаются оба кабеля, работать будет только подключение USB.*
3. Включите систему 2big с помощью переключателя на задней панели.
 4. Система LaCie 2big поставляется с двумя 3,5-дюймовыми жесткими дисками SATA II. Эти диски отформатированы в файловой системе NTFS. Пользователям компьютеров Mac перед работой с системой 2big потребуется отформатировать их повторно. Сведения о форматировании см. в руководстве пользователя на компакт-диске с утилитами для жестких дисков LaCie.
Жесткие диски настроены для работы в режиме быстрого обмена данными FAST (RAID 0). Информацию об изменении режима RAID см. на следующей странице, в разделе «Изменение режима RAID».
 5. **Чтобы включить функцию кнопки быстрого запуска, установите программное обеспечение LaCie Shortcut Button для этой кнопки.**

Изменение конфигурации RAID (дополнительно)

ВНИМАНИЕ! При изменении режимов конфигурации данные, хранящиеся в системе LaCie 2big, будут уничтожены. Поэтому перед выполнением следующих действий необходимо сделать их резервные копии.

ВНИМАНИЕ! Перед изменением конфигурации необходимо правильно вставить жесткие диски в систему 2big.

ПРИМЕЧАНИЕ. Информацию об уровнях RAID см. в руководстве пользователя.

1. Отключите тома привода 2big или выполните их безопасное извлечение. Не выключайте привод 2big.
2. Для того чтобы выбрать режим, вставьте небольшую отвертку с плоским лезвием в паз на поворотном переключателе и поверните ее влево или вправо.
3. Выньте отвертку из переключателя и нажмите ею кнопку подтверждения. Два индикатора состояния привода начнут мигать с большой частотой. Это свидетельствует об изменении режима RAID.
4. Переформатируйте диски. Сведения о форматировании см. в руководстве пользователя на компакт-диске с утилитами для приводов LaCie.

Contact Us

LaCie USA

22985 NW Evergreen Pkwy
Hillsboro, OR 97124
sales@lacie.com

LaCie France

17, rue Ampère
91349 Massy Cedex
sales.fr@lacie.com

LaCie Asia (HK)

25/F Winsan Tower
98 Thomson Road
Wanchai, Hong-Kong
sales.asia@lacie.com

LaCie Asia (Singapore)

Centennial Tower, Level 34
3 Temasek Avenue
Singapore 039190
sales.asia@lacie.com

LaCie Australia

458 Gardeners Rd.
Alexandria, NSW 2015
sales.au@lacie.com

LaCie Belgium

Vorstaal 165/ Bld
du Souverain 165
1160 Brussels
sales.benelux@lacie.com

LaCie Canada

235 Dufferin St.
Toronto, Ontario M6K 1Z5
sales.ca@lacie.com

LaCie Germany

Am Kesselhaus 5
D-79576 Weil Am Rhein
sales.de@lacie.com

LaCie Italy

Centro Direzionale Edificio B4
Via dei Missaglia 97
20142 Milano
sales.it@lacie.com

LaCie Japan K.K.

Uruma Kowa Bldg. 6F
8-11-37 Akasaka, Minato-ku
Tokyo 107-0052
sales.jp@lacie.com

LaCie Netherlands

Postbus 134
3480 DC Harmelen
sales.benelux@lacie.com

LaCie Nordic

(Sweden, Denmark, Norway, Finland)
Sveavägen 90, 5tr
113 59 Stockholm, Sweden
sales.nordic@lacie.com

LaCie Spain

C/ Núñez Morgado, 3, 5º pl.
28036 Madrid
sales.es@lacie.com

LaCie Switzerland

Dauidsbodenstrasse 15 A
4004 Basel
sales.ch@lacie.com

LaCie United Kingdom and Ireland

LaCie LTD - Friendly House
52-58 Tabernacle Street
London, England EC2A 4NJ
UK: sales.uk@lacie.com
Ireland: sales.ie@lacie.com

LaCie Worldwide Export

17, rue Ampère
91349 Massy Cedex, France
sales.intl@lacie.com
support.intl@lacie.com

Visit www.lacie.com for more
information on LaCie products.

