

G432

Surround Sound
Gaming Headset



User Manual



CONTENTS

English	3	Česká verze	78
Deutsch	8	Slovenčina	83
Français	13	Українська	88
Italiano	18	Eesti	93
Español	23	Latviski	98
Português	28	Lietuvių	103
Nederlands	33	Български	108
Svenska	38	Hrvatski	113
Dansk	43	Srpski	118
Norsk	48	Slovenščina	123
Suomi	53	Română	128
Ελληνικά	58	Türkçe	133
По-русски	63	138	العربية
Po polsku	68	143	עברית
Magyar	73		

www.logitech.com/support/g432

КОМПЛЕКТ ПОСТАВКИ

1




1. Игровая гарнитура G432

2. Кабель-разветвитель



3. Переходник USB Audio Adapter

ОСНОВНЫЕ КОМПОНЕНТЫ



1. Гарнитура

2. Съемные амбушюры

3. Микрофон


4. Регулятор громкости

5. Микрофон с функцией отключения звука при повороте

6. Переходник USB Audio Adapter

ПОДГОТОВКА К РАБОТЕ

1




2



www.logitech.com/support/g432

3




4



Для достижения оптимального качества звучания используйте ПО гарнитуры G432.

ИЗМЕНЕНИЕ НАСТРОЕК ГАРНИТУРЫ




Акустика

- Громкость гарнитуры и микрофона




Технология объемного звучания

- DTS Headphone: X 2.0



Эквалайзер

- Регулировка низких и высоких частот



Пользовательский эквалайзер

- Параметры эквалайзера



© 2019 Logitech. Logitech and Logitech G, the Logitech and Logitech G Logos are trademarks or registered trademarks of Logitech Europe S.A. and/or its affiliates in the U.S. and other countries. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

WEB-621-001197.002