

CONGRATULATIONS

You're holding the ROCCAT™ Kova[+] in your hands – the tuned-up successor to the outstanding Kova Gaming Mouse. Whether you're left or right-handed, the Ergo-Stealth design will fit the way you prefer to hold and game with the mouse. One of the key new features is the extensive driver package, comprising the driver, Macro Manager, Macro Presets and the revolutionary EasyShift[+] function.

ROCCAT™ Driver & EasyShift[+]

The Kova[+] is enhanced by a feature-rich driver system. Along with the award-winning Macro Manager, including Macro Presets for gaming, multimedia and office apps, the Kova[+] now also features the innovative EasyShift[+] button – allowing easy doubling of the number of functions configurable on the mouse.

ROCCAT™ Griptech side areas

The ROCCAT™ Kova[+] features enlarged Griptech side areas for left and right-handers alike. These stabilize mouse handling and boost grip in particularly heated gaming situations. Along with the side areas, the mouse body's surface has also been improved and now features a smooth, non-slip coating.

Customizable light system

Use the driver to change colors or the light effects in a second. Get your ROCCAT™ Kova[+] to light up in a variety of legendary colors. The discreetly integrated LEDs on the sides of the mouse cast an atmospheric aura over the desktop, particularly when you activate the 'breathing' function.



SPECIFICATIONS

PACKAGE CONTAINS

- ROCCAT™ Kova[+]
Max Performance Gaming Mouse
- ROCCAT ID Card
- Quick Install Guide

SYSTEM REQUIREMENTS

- Windows® XP, Windows Vista® 32/64 bit, Windows® 7 32/64 bit
- USB 2.0 Port
- Internet connection (for driver installation)

TECH SPECS

- 3200dpi optical gaming sensor
- 130 inches per second maximum speed
- 3G acceleration
- 1000Hz polling rate
- 16-bit data channel
- 2m USB cable

ORGANIZE YOUR DESKTOP WITH ROCCAT™ SDMS
MORE INFO ON WWW.ROCCAT.ORG/SDMS



IMPORTANT DOCUMENT

© 2010 ROCCAT GmbH. All rights reserved. Any product names mentioned in this manual may be trademarks or registered trademarks of their respective owners. Information contained herein is subject to change without notice. ROCCAT GmbH shall not be liable for any errors that may appear in this manual. This publication or parts of it may not be reproduced without the express consent of the publisher.

Germany

22761 Hamburg

Gässerasse 6b, Building N

Office von Bahnenpark

ROCCAT GmbH

WWW.ROCCAT.ORG/SUPPORT

Just send us an email (support@roccat.org) or visit our website:
Our support team will help you with any technical problems –

Should you need assistance ...



A DEFAULT BUTTON ASSIGNMENT

(no driver installed)

1 = Left mouse button

2 = Right mouse button

3 = Middle mouse button & universal scroll

4 = Page forward (Browser)


5 = EasyShift[+] button

6 = Disabled by default
(install the driver to assign a function)

7 = Disabled by default
(install the driver to assign a function)

8 = Mouse wheel up

9 = Mouse wheel down



ROCCAT™ EASYSHIFT[+]

THE DUAL ASSIGNMENT FUNCTION FOR MOUSE BUTTONS

EASYSHIFT[+]: ASSIGNING DUAL FUNCTIONS TO THE MOUSE BUTTONS

For the first time ever, EasyShift[+] allows mouse buttons and scroll-wheel to perform additional tasks by assigning them two functions. In terms of the way it works, the EasyShift[+] button is very similar to the Shift key on a keyboard. For instance, if you hold down the EasyShift[+] button on the Kova[+] and press one of the other standard mouse buttons at the same time, you execute a second function (=dual-assignment).

This makes it possible to assign each individual mouse button, as well as all mousewheel directions (up/down/depressed), not just one, but two individual functions. In doing so, the number of available functions doubles from 8 to 16.

PRACTICAL MACRO CONTROLS:

A good example of using secondary button assignments with the help of EasyShift[+] is when macro controls that are integrated in the driver are selected. Among other examples, here you'll find multimedia functions which you can use to launch, as well as control, your media player using just the mouse. For instance, the mousewheel can be used to control the volume level as soon as you hold the EasyShift[+] button depressed.

In keeping with that, the left and right mouse buttons can then be assigned 'Previous/Next track' in combination with the EasyShift[+] button. Doing this becomes so intuitive that ROCCAT beta testers no longer wanted to do without the EasyShift[+] button after a short while. The best in ergonomics and maximum functionality can finally coexist in harmony.



→ This way you can virtually duplicate the number of buttons by assigning two functions to every single button.

EASYSHIFT[+] EXAMPLES:

EasyShift[+] WoW:

- 5 + 1 = Mount up
- 5 + 2 = Dismount
- 5 + 3 = Autorun
- 5 + 4 = Use trinket
- 5 + 6 = Your macro #1
- 5 + 7 = Your macro #2
- 5 + 8 = Pet attack
- 5 + 9 = Pet follow

EasyShift[+] CS:

- 5 + 1 = Throw HE
- 5 + 2 = Throw flash
- 5 + 3 = Throw smoke
- 5 + 4 = Show scores
- 5 + 6 = Buy CT equipment
- 5 + 7 = Buy T equipment
- 5 + 8 = Primary weapon
- 5 + 9 = Secondary weapon

EasyShift[+] Multimedia:

- 5 + 1 = Previous track
- 5 + 2 = Next track
- 5 + 3 = Mute volume
- 5 + 4 = Switch to full screen
- 5 + 6 = Play or pause
- 5 + 7 = Stop playback
- 5 + 8 = Volume up
- 5 + 9 = Volume down

EasyShift[+] Browser:

- 5 + 1 = Page back
- 5 + 2 = Page forward
- 5 + 3 = New tab
- 5 + 4 = Add bookmark
- 5 + 6 = New window
- 5 + 7 = Print page
- 5 + 8 = Switch to next tab
- 5 + 9 = Switch to previous tab

B DEFAULT BUTTON ASSIGNMENT: EASYSHIFT[+]

(no driver installed)

5 + 1 = Page back (Browser)

5 + 2 = Page forward (Browser)

5 + 3 = Mute volume


5 + 4 = Disabled by default
(install the driver to assign a function)

5 + 6 = Disabled by default
(install the driver to assign a function)

5 + 7 = Disabled by default
(install the driver to assign a function)

5 + 8 = Volume up

5 + 9 = Volume down



DE

ANLEITUNG

- Verbinde den USB-Stecker der ROCCAT™ Kova[+] mit einer freien USB-Schnittstelle.
- Starte deinen Computer und stelle eine Verbindung mit dem Internet her.
- Gebe in die Adresszeile deines Webbrowsers die folgende URL ein „www.roccat.org/support“ und drücke Enter.
- Klicke in der linken Navigationsleiste auf den Punkt „ROCCAT Kova[+]“. Frau den abnende side overfører du den nyeste driversoftware.
- Starte die Treiber-Installation und folge bitte den weiteren Anweisungen auf dem Bildschirm.

DK

INSTRUKTIONER

- Forbind ROCCAT™ Kova[+]s USB-stik med et ledigt USB-interface.
- Start din computer og forbind den med Internettet.
- Indtast følgende URL i adresselinjen af din webbrowser „www.roccat.org/support“ og tryk så Enter.
- Klikke i venstre navigationslinje på punkt „ROCCAT Kova[+]“. Frau den abnede side overfører du den nyeste driversoftware.
- Starte driver-installationen og følg anvisingerne på billedskærmen.

EN

INSTRUCTIONS

- Plug the ROCCAT™ Kova[+]’s USB connector into any free USB port.
- Boot your computer and connect to the internet.
- Enter ‘www.roccat.org/support’ in your browser and hit the return key.
- In the navigation bar on the left, go to ‘ROCCAT Kova[+]’. Download the latest driver from the webpage that opens.
- Start the driver installation process and follow the on-screen instructions.

ES

INSTRUCCIONES

- Enchufe el conector USB del ROCCAT™ Kova[+] a un puerto libre USB.
- Inicia tu ordenador y establece la conexión de Internet.
- Escribe en tu navegador Web la siguiente URL: www.roccat.org/support y pulsa Enter.
- En la barra izquierda de navegación haz clic en el punto “ROCCAT Kova[+]”. En la página que se abre a continuación descarga el software de controlador más actualizado.
- Inicia la instalación del controlador y sigue las instrucciones que aparecen en pantalla.

FI

OHJEET

- Litä ROCCAT™ Kova[+]n USB-pistoke vapaaseen USB-liittäntään.
- Käynnistä tietokoneesi ja luo Internet-yhteys.
- Kirjoita verkkoselaimesi osoiteriville seuraava URL-osoite „www.roccat.org/support“ ja paina Enter.
- Napsauta vasemmassa navigatiopalkissa kohtaa „ROCCAT Kova[+]“. Lataa avautuvalta sivulta uusin ajuriohjelmisto.
- Käynnistä ajurin asennus ja noudata näytöllä näkyviä lisäohjeita.

FR

INSTRUCTIONS

- Reliez la fiche USB de la souris ROCCAT™ Kova[+] à une prise USB libre.
- Démarrer ton ordinateur et connecte-toi à Internet.
- Entre dans la barre d’adresse de ton navigateur l’URL « www.roccat.org/support » et appuie sur Enter.
- Clique dans le menu de navigation de gauche sur « ROCCAT Kova[+] ». Télécharge la dernière version du pilote sur la page qui s’ouvre alors.
- Lance l’installation du pilote et suis les instructions qui s’affichent à l’écran.

PL

INSTRUKCJA

- Podłącz wytkę USB ROCCAT™ Kova[+] do wolnego złącza USB.
- Uruchom komputer i nawiąż połączenie z Internetem.
- Entre w wierszu adresowym przeglądarki wpisz adres URL „www.roccat.org/support” i naciśnij Enter.
- W lewym pasku nawigacji kliknij punkt „ROCCAT Kova[+]“. Z nowo otwartego strony pobierz najnowsze sterowniki.
- Rozpocznij instalację sterowników i postępuj zgodnie z instrukcjami na ekranie.

RU

ИНСТРУКЦИИ

- Соедините USB-штекер ROCCAT™ Kova[+] со свободным USB-портом.
- Запустите компьютер и выйдите в интернет.
- В адресной строке браузера введите адрес „www.roccat.org/support“ и нажмите Enter.
- Нажмите на левой навигационной панели пункт „ROCCAT Kova[+]“. Загрузи с открывшейся страницы самые последние драйвера.
- Запустите инсталляцию драйвера и следуй дальнейшим указаниям на экране.

SE

INSTRUKTIONER

- Sätt ROCCAT™ Kova[+] USB-flisen bos till en ledig USB-girișine tak.
- Bilgisayarını başlat ve internete bağlan.
- Skriw in följande URL i adressfältet på din webbläsare: www.roccat.org/support. Tryck på Enter.
- Klicka på ROCCAT Kova[+] i det vänstra navigationsfältet. Ladda ner den senaste programvaran med drivrutin på den sida som öppnas.
- Starta installationen av drivrutin och följ anvisningarna på skärmen.

TR

TALIMATLAR

- ROCCAT™ Kova[+] USB fışını boş bir USB girişine tak.
- Bilgisayarını başlat ve internete bağlan.
- Web tarayıcısının adres satırına „www.roccat.org/support“ URL adresini gir ve Enter tuşuna bas.
- Sol tarafta bulunan menüdeki „ROCCAT Kova[+]“ üzerine tıkla. İndirilen sayfada en son sürüm sterowniki indir.
- Sürümü kurulumunu başlat ve ekranındaki diğer talimatları takip et.